

Technical Data Sheet



1. Product

160.2 - J-QUANT QUAT 0 - 25 - 1000 mg/L, 100 strips/pk

2. Instructions for use

- Immerse an indicator strip in the test solution for 5 seconds.
- Shake off excess solution.
- Immediately compare the colour produced on the strip against the colour chart.

3. Measuring range

0 - 25 - 50 - 100 - 250 - 500 - 1000 mg/L



4. Application

The J-QUANT QUAT test strip detects the level of quaternary ammonium compounds in cleaning solutions. This enables the user to verify the required level of disinfectant is present before cleaning commences.

5. Shelf Life

3 years from manufacturing date.

6. Contents

100 strips

7. Weights & Dimensions

Strip dimension: 83mm x 5mm

8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

Johnson Test Papers Ltd
Hainge Park, Hainge Road
Oldbury, West Midlands
B69 2NU, United Kingdom

T: +44 (0)121 557 3883
F: +44 (0)121 557 8235
E: info@jtp.uk.com
W: www.johnsonstestpapers.com

Registered in England
Company Reg No: 4112470
VAT No: GB 754 6913 04

