

# Technical Data Sheet

## 1. Product

165.5C - J-QUANT Peroxide 100 mg/L, 100 strips/pk

## 2. Instructions for use

- Immerse an indicator strip in the test solution for 2 seconds.
- Shake off excess solution.
- Wait 30 seconds.
- Compare the colour produced on the pH strip with the colour chart.

## 3. Measuring range

0 - 1 - 3 - 10 - 30 - 100 mg/L



## 4. Application

The J-QUANT Peroxide test strip detects residual peroxides, for example, in drinking water, pools, and hot tubs where Hydrogen Peroxide may be used as a disinfectant.

## 5. Shelf Life

2 years from manufacturing date when stored between 2 - 8°C.

## 6. Contents

100 strips

## 7. Weights & Dimensions

Strip dimension: 83mm x 5mm

## 8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.