

# Technical Data Sheet

## 1. Product


167.5C - J-QUANT Peracetic Acid 0 - 50 mg/L, 100 strips/pk

## 2. Instructions for use

- Immerse an indicator strip in the test solution for 3 seconds.
- Shake off excess solution.
- Wait 45 seconds.
- Compare the colour produced on the strip against the colour chart.

## 3. Measuring range

0 - 5 - 10 - 20 - 30 - 50 mg/L



## 4. Application

The J-QUANT Peracetic acid test strip detects residual peracetic acid, for example, in the food, cosmetic, beverage, pharmaceutical and medical industries, where peracetic acid may be used as a disinfectant.

## 5. Shelf Life

3 years from manufacturing date.

## 6. Contents

100 strips

## 7. Weights & Dimensions

Strip dimension: 83mm x 5mm

## 8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.