

Technical Data Sheet



1. Product

168.5C - J-QUANT Peracetic Acid 0 - 500 mg/L, 100 strips/pk

2. Instructions for use

- Immerse an indicator strip in the test solution for 1 second.
- Shake off excess solution.
- Wait 10 seconds.
- Compare the colour produced on the strip against the colour chart.

3. Measuring range

0 - 100 - 150 - 200 - 250 - 300 - 400 - 500 mg/L



4. Application

The J-QUANT Peracetic acid test strip detects residual peracetic acid, for example, in the food, cosmetic, beverage, pharmaceutical and medical industries, where peracetic acid may be used as a disinfectant.

5. Shelf Life

3 years from manufacturing date.

6. Contents

100 strips

7. Weights & Dimensions

Strip dimension: 83mm x 5mm

8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

Johnson Test Papers Ltd
Hainge Park, Hainge Road
Oldbury, West Midlands
B69 2NU, United Kingdom

T: +44 (0)121 557 3883
F: +44 (0)121 557 8235
E: info@jtp.uk.com
W: www.johnsonstestpapers.com

Registered in England
Company Reg No: 4112470
VAT No: GB 754 6913 04

